

U S. Express Mail No. EL926457574US
Title: SENSOR SUBSTRATE AND METHOD G
FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty: Ted Rittmaster –047711-0280
Sheet 1 of 17




U.S Express Mail No. EL926457574US

Title. SENSOR SUBSTRATE AND METHOD OF
FABRICATING SAME
Foley & Lardner – 310-277-2223

Atty Ted Rittmaster –047711-0280
Sheet 2 of 17





FABRICATING SAME Foley & Lardner – 310-277-2223 Atty. Ted Rittmaster –047711-0280 Sheet 3 of 17

| 20 | Obtain substrate material |
|----|---------------------------|

- Form vias 22
- Fill vias 24
- 26 Deposit conductive layers
- Place electronics and sensing element on substrate 28

U S. Express Mail No EL926457574US
Title. SENSOR SUBSTRATE AND METHOD OF FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty: Ted Rittmaster –047711-0280
Sheet 4 of 17




- Obtain substrate material 30
- 32 Form vias
- Anneal substrate 34
- Fill vias 36
- Fill meniscus 38
- Lap off excess 40

U.S Express Mail No EL926457574US
Title. SENSOR SUBSTRATE AND METHOD OF
FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty Ted Rittmaster –047711-0280
Sheet 5 of 17 Sheet 5 of 17

- 42 Place screen on top of substrate
- Push filler through screen 44
- Pull vacuum on opposite side of substrate 46
- Fire substrate 48
- Check via and repeat as necessary 50

US Express Mail No EL926457574US
Title: SENSOR SUBSTRATE AND METHOD OF FABRICATING SAME
Foley & Lardner - 310-277-2223
Atty: Ted Rittmaster -047711-0280
Sheet 6 of 17



U.S Express Mail No. EL926457574US
Title: SENSOR SUBSTRATE AND METHOD OF
FABRICATING SAME


Foley & Lardner – 310-277-2223 Atty: Ted Rittmaster –047711-0280 Sheet 7 of 17



- 70 Place substrate into vacuum
- 72 Print filler on top of meniscus
- 74 Vent substrate to atmosphere
- 76 Fire substrate

U S Express Mail No. EL926457574US

Title: SENSOR SUBSTRATE AND METHOD
FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty: Ted Rittmaster –047711-0280
Sheet 8 of 17




U S Express Mail No. EL926457574US

Title: SENSOR SUBSTRATE AND METHOD
FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty. Ted Rittmaster –047711-0280
Sheet 9 of 17

| 80 | Apply metalization pattern to electronics side of substrate |
|----|---|
| 82 | Place pillars on top of vias |
| 84 | Coat substrate |
| 86 | Dissolve pillars |
| 88 | Apply metalization layer to electronics side of subtrate |
| 90 | Apply metalization pattern to sensing element side of substrate |
| 92 | Place caps over via location |


Fig. 9



U.S. Express Mail No. EL926457574US

Pheer 10 of 16.


FABRICATING SAME
FABRICATION OF 16.



U S. Express Mail No. EL926457574US
Title: SENSOR SUBSTRATE AND METHOD OF ABRICATING SAME
foley & Lardner – 310-277-2223

| roley | & Lardner — | 51 | 0-277 - 22 | 23 |
|-------|---------------|----|-------------------|-------|
| Atty: | Ted Rittmaste | er | -047711 | -0280 |
| Sheet | 12 of 17 | _ | _ | _ |
| | | | | |

| 110 | Epoxy IC to pad |
|-----|------------------------------------|
| 111 | Wire bond leads |
| 112 | Place solder paste on capacitor |
| 113 | Layer solder paste along gold ring |
| 114 | Reflow substrate |
| 115 | Clean |
| 116 | Hold lid over substrate and bake |
| 117 | Solder lid onto substrate |



- Identify material grain 120
- Cut blanks 122
- Anneal blanks 124
- Form blanks into desired shape

U.S. Express Mail No. EL926457574US Title: SENSOR SUBSTRATE AND METHOD OF

FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty: Ted Rittmaster –047711-0280
Sheet 14 of 17

- Put substrate into chamber 130
- Place leak test fluid into reservoir 132
- Pressurize chamber and pour leak test fluid over substrate
- Release pressure and observe 136

U S. Express Mail No EL926457574US

Title. SENSOR SUBSTRATE AND METHOD OF FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty: Ted Rittmaster –047711-0280
Sheet 15 of 17


| 140 | Place board into fixture |
|-----|--|
| 142 | Electroplate electrodes |
| 144 | Rinse |
| 146 | Silver plate reference electrode |
| 148 | Rinse |
| 150 | Put board into reference inducing solution |
| 152 | Coat electroplated surface |
| 154 | Cure coating |
| 156 | Dispense buffer |
| 158 | Laser trim |
| 160 | Coat board |
| 162 | Anneal |
| 164 | Coat |
| | |

Anneal

166

U S. Express Mail No EL926457574US

Title SENSOR SUBSTRATE AND METHOD FABRICATING SAME
Foley & Lardner - 310-277-2223
Atty: Ted Rittmaster -047711-0280
Sheet 16 of 17





U.S. Express Mail No. EL926457574US

Title SENSOR SUBSTRATE AND METHOD OF FABRICATING SAME
Foley & Lardner – 310-277-2223
Atty. Ted Rittmaster –047711-0280
Sheet 17 of 17

| 170 | Form vias and anneal substrate |
|-----|---|
| 172 | Fill vias and fire substrate |
| 174 | Screen print and fire conductors on electronics side of substrate |
| 176 | Pattern photoresist |
| 178 | Form metalization layer on electronics side of substrate |
| 180 | Deposit pillars on electronics side of substrate |
| 182 | Deposit alumina over electronics side of substrate |
| 184 | Remove pillars |
| 186 | Pattern photoresist |
| 188 | Form metalization layer on alumina |
| 190 | Pattern photoresist on sensing element side of substrate |
| 192 | Form metalization layer on sensing element side of substrate |
| 194 | Deposit caps over vias on sensing element side of substrate |
| 196 | Remove unwanted metal on both sides of the substrate |

FIG. 17